

Function Table of the Menu Key SM 2 Plus Powder

(Connection to the Feeding Computer; Program Version 01.01)

*Menu	**Submenu	***Further Menus
Hand Functions	Emptying mixer start?	
	Water boiler start?	
	MP start?	
	Additive start?	
	Mixer start?	
	Box valve 1 open?	
	Box valve 2 open?	
	Boiler fill?	
Portion Values	Concentration	$0 \text{ g/l} \le x \le 255 \text{ g/l}$
	Additive	$0 \text{ g/l} \le x \le 25 \text{ g/l}$
	Operating mode	Restr. fix conc.
		Restr. var. conc.
		Adlib mode
Calibration	Water boiler start?	targ.: 500 ml
	MP start?	targ.: 100 g
	Additive start?	targ.: 10 g
	Detergent start?	targ.: 10 ml
Machine Values	Intermediate mix	x min
	Afterrun mixer	x sec
	Emptying mixer	x min
	Distribution pause	xx sec
	Box 1 / Box 2	Turn-on delay
		Turn-off delay
Diagnosis	Valves	Water valve boiler open?
		Mixer valve open?
		Air valve open?
		Valve box 1/2 open?
		Mixer start?
		Powder motor start?
	Motors	Additive dispenser start?
		Detergent pump start?
		Feeding pump start?
	Sensors	Rod electrode covered/free?
		Point electrode covered/free?
		Supply electrode covered/ free?
		Temperature ok/too low?

Diagnosis	Calibration	Water running time: x.xx sec
		MP running time: x.xx sec
		Additive running time: xx.xx sec
		Detergent running time: x.xx sec
	Interface	Signal portion active/not active
		Signal additive active/not active
		Selection box 1/2 active/not active?
		Signal ready activate?
	Checking	Power failures
		Back-ups
		Cleaning fault
		Water check
	Version	System-Machine
*Press Enter to move from the main menus to the corresponding submenus	**Press Arrow Up or Arrow Down to move from one submenu to another. Select further menus by pressing the Enter key	*** Press Enter and subsequently Arrow Up or Arrow Down to modify these menus.